SERVICE MANUAL

Model: DS-530

Edition	Month	Year
1st	Oct	2002
2nd		
3rd		
4th		

Shanghai Teraoka Electronic Co., Ltd. --- Technical Support Dept.

A/18F, East Tower of New HuaLian Mansion, 755# HuaiHai Zhong Road, Shanghai China 200020

Tel: +86-21-6473-9918 Fax: +86-21-5490-4530 E-mail: steservice@digi-scale.com

CONTENTS

1. General Specification ---------- 1
1.1. General Layout ---------- 1
1.2. Purpose ---------- 2
1.3. Features ---------- 2
1.4. Operating Condition ---------- 2
1.5. Analog Specification ---------- 2
1.6. Capacity / Minimum Graduation / Tare Range ---------- 3
1.7. Dimensions ---------- 3
1.8. External Connectors ---------- 3
1.9. Main Components ---------- 3
1.10. Existing parts to be used ---------- 3
2. General Layout ---------- 4
2.1. Key Function ---------- 4
2.2. Display & Indicators ---------- 4
3. Initial Setup ---------- 5
3.1. Location Of SPAN SW ---------- 5
3.2. Specification Setting ---------- 5
3.3. Internal Count and A/D Count ---------- 5
3.4. Specification Enter and Span Adjustment ---------- 6
3.5. Specification Setting List ---------- 6
4. Main Operation ---------- 7
4.1. Power On/Off ---------- 7
4.2. Automatic Shut Off Timer Setting ---------- 7
4.3. Weight Reset ---------- 7
4.4. One Touch Tare ---------- 7
5. Error Message ---------- 8
6. Hardware Detail ---------- 9
6.1. Microcomputer ---------- 9
6.2. Electrical Blocks Connection Diagram ---------- 11
6.3. Physical Connection Diagram ---------- 12
6.4. Circuitry Diagram ---------- 14