4. Main Operation

4.1. Power On/Off

Operation	Display	Zero	Tare	Remarks
[On/Off]	8 8 8 8 8 8			Display for 1 second. Blank for 1 second.
Ready to operate	0	▼		Weighing mode
[On/Off]				

*Note: 888888 means all segments displayed.

4.2. Automatic Shut Off Timer Setting

Operation	Display	Zero	Tare	Remarks
				Machine off
Keep depressing [On/Off] for 3 seconds	3			Set automatic shut-off timer to 3 minutes
Release [On/Off]	8 8 8 8 8 8			Segment checking
Ready to operate	0	▼		Weighing Mode
[On/Off]				Machine off
Keep depressing [On/Off] for 6 seconds	3 10			Set automatic shut-off timer to 10 minutes
Release [On/Off]	8 8 8 8 8 8			Segment checking
Ready to operate	0	▼		Weighing Mode
[On/Off] key				Machine off
Keep depressing [On/Off] for 9 seconds	3 10 9 9 9			Set to NO automatic shut off
Release [On/Off]	8 8 8 8 8 8			Segment checking
Ready to operate	0	▼		Weighing Mode.

*Note: The setting data registered in the memory until new data is set.

4.3. Weight Reset

Operation	Display	Zero	Tare	Remarks
Load 60g on platter	6 0			
[Re-Zero]	8 8 8 8 8 8			Weight resetting
	0	▼		Weighing mode
Put 2000g on platter	2 0 0 0			
[REZERO]	8 8 8 8 8 8			Weight resetting
	2 0 0 0			Exceeded Re-Zero range
Remove 2000g	0	▼		Weighing mode

4.4. One Touch Tare

Operation	Display	Zero	Tare	Remarks
Load 600g	6 0 0			Net weight
[Tare]	0	▼		Perform tare weight
Remove 600g	- 6 0 0		▼	Minus tare weight
[Tare]	0	▼		Tare weight clear