2. General Layout

2.1. Key Function

- Re-Zero Key: Reset weight display to zero
- Tare Key: Set or clear tare value
- On/Off Key: Turn the power ON or OFF

2.2. Display and Indicators

2.2.1. Display Specification

- Weight Display: 6 digits with ZERO, TARE, Low Battery indication
- Special Display: 6 digits
- Decimal point: Selectable by SPEC.

2.2.2. Indicators

- Zero: Light on when zero point is adjusted and weight is stable
- Net: Light on when tare subtraction is performed
- Battery: Light on when battery is weak